



ALBERT CLOCK Alarm

user manual



Slide the battery compartment cover down with your thumb. Carefully remove one battery, remove the green insulation strip and reinsert the battery. The clock starts automatically.

First, press this button to enter and skip through the MENU. Then, press these buttons to modify the values inside the MENU points.



OR

Press this button to instantly access the level of difficulty settings.

Press this button to instantly access the alarm settings.

MENU - 1: MODE 12H- OR 24H-CLOCK


You can switch in between 12-hour and 24-hour clock.




MENU - 2/3: SET TIME

Change time settings for hours and minutes. In 12h-clock mode, AM/PM info appears on the left.

First the hours (blinks) ...





... then the minutes (blinks).



MENU - 4: LEVEL OF DIFFICULTY


Choose in between 6 different levels of difficulty. For example: level 1 works with addition and subtraction, level 6 with multiplication and division.

ALL = Levels 1-6 are used randomly




MENU 5: CALCULATION SPEED

Choose between 4 different speed levels. Example: in level 1 the calculation term changes 1 time per minute. In level 4 the term changes 4 times per minute, i.e. every 15 seconds.




MENU 6: DIVISION SYMBOLS

Choose in between 2 different division symbols (: or /)




MENU 7, 8 AND 9: SET THE ALARM


Set the time for the alarm. First the hours...




... then the minutes ...



... the star indicates "alarm on" ...



... the point indicates "alarm off".



back to Menu 1.